

CARE INSTRUCTIONS



FABRIC, FINISH & STRAP CARE

	PVC, PVC WICKER WEAVE	ACRYLIC POLY/OLEFIN, PVC/OLEFIN, PVC/ACRYLIC	CLASSICS WROUGHT IRON FRAMES	ALUMINUM FRAMES & TOPS	VINYL STRAPS
CLEANING & MAINTENANCE	For best results, clean regularly with mild detergent and warm water. Cleaning will help prevent mildew by washing out dirt particles that may become trapped. Shake out excess moisture after rinsing and allow to dry thoroughly before storing.	Spot wash by sponging briskly with a mild soap in lukewarm water (do not exceed 100°F). Thoroughly rinse with clean water to remove soap. Allow to air dry completely before storing.	Clean with warm, soapy water. Damage to the paint finish may cause corrosion, touch up with paint immediately. To maintain the gloss on non-textured finishes, protect with a fine automotive wax.	Clean with a solution of warm water and mild soap. Use a fine automotive wax to maintain gloss on non-textured finishes.	Clean with mild laundry detergent and warm water. Strap contains an effective fungicide and UV stabilizers.
REMOVING STAINS, MILDEW, ETC.	Clean with a solution of warm water, mild laundry detergent, and chlorine bleach (no more than 1/4 cup per three gallons of water). Never use a solvent-type solution.	Same as above.	Woodard's multi-step finishing process results in a stain-resistant finish. Severe stains may require light sanding and touch-up painting.	Woodard's multi-step finishing process results in a stain-resistant finish. Severe stains may require light sanding and touch-up painting.	To remove scuff marks on vinyl straps, apply toothpaste or gentle abrasive to a clean, dry cloth and rub gently. To remove mildew, use a solution of warm water, mild laundry detergent, and chlorine bleach (no more than 1/4 cup per three gallons of water). Never use a solvent-type solution.
INSECT REPELLENTS & SUNTAN LOTIONS	Not recommended. Insect repellents and suntan lotions can reduce the life of PVC, accelerate fading and stain fabrics. To avoid damage, wipe clean with mild laundry detergent and warm water.	Not recommended. Insect repellents and suntan lotions can reduce the life of fabric, accelerate fading and stain fabrics. To avoid damage, wipe clean with mild laundry detergent and warm water. Do not use bleach or harsh detergents under any circumstances.	The finish on Woodard furniture is formulated and baked on to make it highly resistant to repellents and lotions. However, to avoid discoloration, clean metal parts of these products frequently.	The finish on Woodard furniture is formulated and baked on to make it highly resistant to repellents and lotions. However, to avoid discoloration, clean the frame as soon as possible after the exposure.	Not recommended. Insect repellents can reduce the life of vinyl plastic, accelerate fading and stain fabrics. To avoid damage, wipe clean with mild laundry detergent and warm water.
SPECIAL INSTRUCTIONS	DO NOT USE solvents, scouring agents, carbon tetrachloride, undiluted bleach, janitorial cleansers or gasoline. If in doubt about using a detergent, choose an inconspicuous area and test the cleaner.	DO NOT USE STEAM. Acrylic fibers are made of 100% acrylic fiber and are thermoplastic or heat sensitive. When spot washing, use lukewarm water (under 100°F). Allow to air dry. Do not use solvents, carbon tetrachloride, scouring agents, bleach, janitorial cleansers, gasoline or brushes.	Frame finish touch-up instructions: When covering small spots of surface rust, clean area by sanding lightly and wipe immediately to prevent rust. When preparing scratched areas for touch-up painting, rub lightly with a fine steel wool to smooth the surface and improve paint adhesion. Apply thin coats of touch-up paint and allow ample drying time between coats.	Frame finish touch-up instructions: When using touch-up paints, please follow instructions and cautions on product labels. If covering scratches, rub lightly with a fine steel wool to smooth the surface and improve paint adhesion. Apply thin coats of touch-up paint and allow ample drying time between coats.	DO NOT USE solvents, scouring agents, carbon tetrachloride, undiluted bleach, janitorial cleansers or gasoline. If in doubt about using a detergent, choose an inconspicuous area and test the cleaner.

GLASS & TOP CARE

	TEMPERED GLASS	IMPRESSION & STONE MOSAIC TOPS
CLEANING & MAINTENANCE	Clean regularly with a soft cloth, a mild detergent and warm water. Buff dry with a clean, lint-free cloth.	Clean regularly with a soft cloth and warm water. For stubborn dirt, wipe gently with a moist sponge and dry with a clean, soft cloth.
REMOVING STAINING, MILDEW, ETC.	Same as above.	Wet area immediately with warm water and a mild detergent. Let stand for a few minutes and wipe clean. If necessary, follow with a second cleaning using a soft cloth, warm water and a mild detergent. Wipe dry with a cloth.
SPECIAL INSTRUCTIONS	DO NOT USE solvents, scouring agents, carbon tetrachloride, undiluted bleach, janitorial cleansers or gasoline.	DO NOT USE solvents, scouring agents, carbon tetrachloride, undiluted bleach, janitorial cleansers or gasoline. Do not expose top to nail polish or acetone as these may damage the finish.